

NOTES:

- 1. ARROWS SHALL BE INSTALLED AT THE BEGINNING OF ALL LEFT TURN AND RIGHT TURN POCKETS.
- 2. ARROWS SHALL BE INSTALLED AT THE BEGINNING AND END OF LEFT OR RIGHT TURN POCKETS 100' OR GREATER IN LENGTH.
- 3. STRIPING DETAILS AND PAVEMENT MARKINGS SHALL CONFORM TO THE LATEST EDITION OF THE CALIFORNIA MANUAL ON UNIFORM TRAFFIC CONTROL DEVICES (CA MUTCD).

4	CITY OF LONG BEACH, DEPARTMENT OF PUBLIC WO	ORKS	STANDARD PLAN NO.
2	TRAFFIC STRIPING AND ARROW MARKINGS POCKETS, OPTIONAL TURN LANES AND THRO	FOR TURN OUGH LANES	308
NO. DATE	APPROVED BY: DATE	: 3/29/19	SHEET 1_0F_1_